


T4 (052-XXX) TO RY4A WIRING CONFIGURATION

REGULATED PSU



***** IMPORTANT *****

USE T4 INSTALLATION SHEET AND T4 INSTALLATION GUIDE FOR T4 FUNCTIONS REFERENCE

ALL WIRES NOT USED MUST BE TERMINATED SAFE.

T4(052) LIGHT CURTAIN NEED TO BE SET IN AUTO-START VIA DIPSWITCH SETTING. REFER TO T4(052) INSTALLATION GUIDE.

